

Installation instruction



1. Put the graphic and top bar together like this



2. Remove the end caps



3. Open the top bar



4. Insert the graphic and press the top bar



5. Reattach the end caps



6. Put the graphic and base leader together like this



7. Remove the 3M tape from the leader



8. Adhere the graphic to the lead sheet



9. Hold the graphic and remove the spring key



10. Allow the graphic to go into the base